

## HT2-SMK HomeTroller Series 2 Surface Mount Kit Assembly Instructions

This document contains important information that is specific to the installation of the HT2-SMK suface mount kit. Please follow the instructions carefully to ensure proper installation.

## Installing the Brackets

1. POWER DOWN AND UNPLUG your HomeTroller to avoid an electrical shock. Then, gently slide the silver plastic trim pieces from the front and back of the HomeTroller.

 Gently slide the top cover back (in the direction of the red arrow) and then lift up to remove. Now flip the top cover upside down. The mounting brackets will be installed on the outside of the cover and the mounting bolts will be secured to it from the inside.

3. With the top cover inverted, position the mounting bracket as shown and secure with (2) of the provided bolts. Be sure to center the bracket by using the center row of holes with each bolt positioned in the 3<sup>rd</sup> hole in from the outer edge.

## NOW REPEAT THIS PROCEDURE FOR THE OTHER SIDE OF THE COVER.

4. When both brackets are attached, replace the top cover by gently sliding it back onto the chassis.

NOTE: the front side of the cover has mounting clips attached to it. Be sure to orient the cover correctly! With the cover back in position, replace the silver plastic trim pieces to complete the assembly.

Note: Wall mounting hardware is not included.







