InTouch™ Wireless Controls

Model CA600

Single-Pole / Multi-Pole Dimmer 600 Watt Switch



APPLICATIONS

- This wall mounted device features dimming of incandescent loads up to 600 watts
- Single pole, 3-way wiring or 4-way wiring Routing slave capabilities for launching
- mini-scenes
- Includes interchangeable rocker plates

SPECIFICATIONS

Operating Temperature Range: 32°F (0°C) to 104°F (40°C)

Power Consumption: 3.0W Maximum Dimming: Fade-on & Fade-off, 1% Dimming

(100 Increments)

Ratings: 120VAC, 50/60Hz Maximum Maximum Wattage: 600W

Minimum Wattage: 40W Colors: Includes white, ivory, and light almond

snap-on rocker plates

Connections: Black-Line, Blue-Load, Red-Traveler, Green-Ground

RF INFORMATION Minimum Range: 50ft indoor; 100ft outdoor Frequency: 908.42 MHz


NETWORK INFORMATION

MHzMesh Network: Each line powered node acts as a repeater to route distant signals

Data Rate: 9600 bits/second Size: 232 Z-Wave Nodes







The CA600 In-Wall Dimmer is a Z-Wave™ enabled device which is fully compatible with any Z-Wave enabled network. Z-Wave enabled devices display the Z-Wave logo and guarantee connectivity and interoperability between devices. Each line powered node in a Z-Wave network is designed to act as a repeater forming a mesh network eliminating radio "dead spots" and providing the highest level of reliability.

Features

- Multiple location On/Off and dimming when used with wireless accessory controls.
- Multiple location On/Off control using conventional 3-way or 4-way wiring and
- Lights fade up or down when turned on or off.
- Automatically returns to last level in the event of power fluctuations.
- Light levels can be set by pressing and holding the rocker until the desired light level is reached.
- Mini-scenes allows local control of connected load plus up to 5 additional Z-Wave devices.
- Full 230 device scene control when used with Intermatic InTouch™ server (CA5500BR)
- Dimmer always operates local load, does not require central control system.

Rocker Color Conversion

The frame and rocker color of this device can be converted to match interior design requirements. Simply use one of the included color plates (white, ivory or light almond) and proceed as follows (please note that the device must be removed from the junction box to change the rocker, follow the installation instructions and warnings).

- 1. Select the color of the face you desire.
- 2. The frame has snaps on its sides. Using a small screwdriver or thumbnail, gently remove the frame and rocker from the housing body.
- 3. Take the new frame and position it properly to the housing body. Notice that the locking snaps will align in only the proper direction. Line up the plastic snaps with the slots in the housing body and snap into place.
- 4. The frame snaps in with an audible click. Ensure that both snaps are secure. Replace the device in the junction box following installation instructions. The color conversion is complete.

Installation Data

